

Sequential Mixer Tap Installation instructions



These instructions illustrate how to install BPLMON (Sequential basin mixer tap).

These instructions can be followed either prior or after installation of the basin to the wall.



1) Attach the two bolts to the bottom of the tap (short threaded end of bolts)



2) Push one of the FlexiTales through the desired tap-hole



3) Attach FlexiTale to the base of the tap and position the tap in place over the tap-hole



4) From the underside, attach second Flexitale to underside of tap



5) Position rubber washer over flexitales and bolts, followed by the metal washer. Use bolts to secure tap in place.